RIGID DANBUOY INSTRUCTIONS





Rigid Ocean Danbuoy RORC Compliant - 2 piece Telescopic

The Seago telescopic Danbuoy complies with RORC and ISAF racing regulations (when extended).

Stainless Steel Holder (push-pit mountable) for telescopic Dan-buoy available.

- Telescopic
- RORC and ISAF compliant
- · High visibility red and yellow OSCAR man-over-board flag
- · Durable, inflatable float
- · Concealed lead weight
- · Bright yellow to attract attention
- High strength fibreglass construction
- · Replaceable light with 8 hours run time
- 5m floating line included
- · Spare light, flag and batteries available (contact Seago directly)

Fitting the Danbuoy (holder required)

- Firstly, inspect the Danbuoy to ensure there is no damage.
- Check the light is working, pull a small amount of the top tube up and slide the flag down the top tube to make room for the light to be fitted.
- Push the light in as far as it goes (this stops the flag coming off)
- Unwind the rope from the light and secure to the push-pit or holder (holder not included - optional extra)

Using the Danbuoy

Get familiar with the product and test it after purchase to ensure it performs correctly. Seago recommend this is performed periodically.

- Pull out the extension sections until the taper provides a secure grip
- Release flag
- · Ensure the rope runs free

The Danbuoy should be mounted on board so that it can be easily and quickly deployed

To stow Danbuoy

- · Roll the flag tightly around the top tube section and secure
- · Lower extension and tidy rope
- Disable automatic mechanism on light by replacing the small yellow clip

Checking the light (annually)

- Ensure the battery is properly fitted and in date.
- · Batteries must be changed every 3 years regardless
- Pull the yellow cord to release clip, the light should flash
- · Replace the clip back in the light to turn it off

Danbuoy holder (optional extra)

